



Pratissoli

Technical Infos



Temperature conversions

In the column marked with the star (*) you read the temperature you want to change: if it is in °F you will read the correspondent in °C in the column marked with (C); if it is in °C you will read the correspondent in °F in the column marked with (F).

°C	*	°F	°C	*	°F	°C	*	°F	°C	*	°F
-58.5	-73.3	-100.0	-7.22	19	66.2	7.78	46	114.8	22.8	73	163.4
56.7	-70.0	-94.0	-6.67	20	68.0	8.33	47	116.6	23.3	74	165.2
-51.1	-60.0	-76.0	-6.11	21	69.8	8.89	48	118.4	23.9	75	167.0
-45.6	-50.0	-58.0	-6-56	22	71.6	9.44	49	120.2	24.4	76	168.8
-40.0	-40.0	-40.0	-5.00	23	73.4	10.0	50	122.0	25.0	77	170.6
-34.4	-30.0	-22	-4.44	24	75.2	10.6	51	123.8	25.6	78	172.4
-28.9	-20.0	-4	-3.89	25	77.0	11.1	52	125.6	26.1	79	174.2
-23.3	-10.0	14	-3.33	26	78.8	11.7	53	127.4	26.7	80	176.0
-17.8	0	32.0	-2.78	27	80.6	12.2	54	129.2	27.2	81	177.8
-17.2	1	33.8	-2.22	28	82.4	12.8	55	131.0	27.8	82	179.6
-16.7	2	35.6	-1.67	29	84.2	13.3	56	132.8	28.3	83	181.4
-16.1	3	37.4	-1.11	30	86.0	13.9	57	134.6	28.9	84	183.2
-15.6	4	39.2	-0.56	31	87.8	14.4	58	136.4	29.4	85	185.0
-15.0	5	41.0	0	32	89.6	15.0	59	138.2	30.0	86	186.8
-14.4	6	42.8	0.56	33	91.4	15.6	60	140.0	30.6	87	188.6
-13.9	7	44.6	1.11	34	93.2	16.1	61	141.8	31.1	88	190.4
-13.3	8	46.4	1.67	35	95.0	16.7	62	143.6	31.7	89	192.2
-12.8	9	48.2	2.22	36	96.8	17.2	63	145.4	32.2	90	194.0
-12.2	10	50.0	2.78	37	98.6	17.8	64	147.2	32.8	91	195.8
-11.7	11	51.8	3.33	38	100.4	18.3	65	149.0	33.3	92	197.6
-11.1	12	53.6	3.89	39	102.2	18.9	66	150.8	33.9	93	199.4
-10.6	13	55.4	4.44	40	104.0	19.4	67	152.6	34.4	94	201.2
-10.0	14	57.2	5.00	41	105.8	20.0	68	154.4	35.0	95	203.0
-9.44	15	59.0	5.56	42	107.6	20.6	69	156.2	35.6	96	204.8
-8.89	16	60.8	6.11	43	109.4	21.2	70	158.0	36.1	97	206.6
-8.33	17	62.6	6.67	44	111.2	21.7	71	159.8	36.7	98	208.4
-7.78	18	64.4	7.22	45	113.0	22.2	72	161.6	37.2	99	210.2
									37.8	100	212.0

